



1-866-443-6623  
[www.holdupdisplays.com](http://www.holdupdisplays.com)

## HD118-FW Vertical Suppressor Holder



Choose location for hanger. Drive screws through mounting holes of hanger into wall using a Phillips screwdriver. If a wall stud is not found, these pilot holes are necessary for installing the drywall anchors. To do this, use the screwdriver to push and turn the anchor clockwise until flush. Remount hanger with screw into anchor. **DO NOT REUSE ANCHORS.**