

Item#: HD96 Slatwall Gun Lock



1) ATTACH BEDSIDE LOCK TO TRIGGER GUARD



2) INSERT TAB INTO SLATWALL



3) INSERT PLATE INTO SLATWALL



4) PRESS PLATE DOWN SO TAB Goes Through Bottom Slot and you are able to attach the lock.

*NOTE: PUSHING PLATE INTO WALL SHOULD BE DIFFICULT.
THIS CREATES THE TENSION NEEDED TO KEEP PLATE
FROM MOVING ALONG WALL.